



101.196

Easy Rider


Tools required:




Ruler




Pencil




Jigsaw /
scroll saw




Machine vice



Bending aid



Drill bit




Wrench




Slot screwdriver




Hammer




Wood glue




Pricking awl




Adhesive tape



Engineer's file



PUK Saw



Sandpaper



Soldering iron
and solder


Note

The OPITEC handicraft packs are not toys in a typical off-the-shelf sense, but rather additional teaching and learning material for educational purposes. This craft pack may only be constructed by children and adolescents under the guidance and supervision of experienced adults. Not suitable for children under 36 months. Choking hazard!


Parts list	Number of pieces	Dimensions (mm)	Description	Part no.
Wooden strip	2	50x5x5	Reinforcement bearing blocks	1
Wooden strip	2	250x25x10	Fender bearing block/side parts	2
Wooden strip	2	200x50x10	Backrest/chassis/storage block	3
Wooden strip	1	125x20x10	Fork	4
Wooden wheel with rubber tires	3	ø60	Wheels	5
Gear 38 teeth	2	ø40	Propulsion	6
Gear 13 teeth	2	ø15	Propulsion	7
Tack bar	3	M4x150	Rear axle/steering	8
Cylinderhead screw	1	M4x35	Wheel mounting front axle	9

Instruction 101196
Easy Rider


Parts list	Number of pieces	Dimensions (mm)	Description	Part no.
Cylinderhead screw	3	M4x25	Battery connection	10
Cylinderhead screw	1	M4x20	Motor mounting	11
Nuts	30	M4	Fixing	12
Head nut	3	M4	Fixing	13
Toothed washer	13	M4	Fixing	14
Washer	4	M4	Fixing	15
Brass sleeve	1	∅5x15	Bore front wheel	16
Brass sleeve	1	∅5x25	Bearing block bore	17
Brass sleeve	1	∅5x45	Bearing block bore	18
Welding rod	2	∅2x100	Handlebars	19
Electric motor	1	∅23	Propulsion	20
Spring steel clip	1	23x27	Bracket engine	21
Reducer	1	4/2	Gear to shaft reduction	22
Screw hooks	2	20	Battery holder	23
Feather brass strip	1	0,4x8x50	Battery switch	24
Rubber rings	2	∅60	Battery holder	25
Hard rubber disc	1	∅13mm/∅4	Steering	26
Luster terminal	1	3-pole		27
Wooden beads	2	∅10		28
Switching wire	2	500	Wiring	29




Transfer the template (page 11) for the base plate (1a+1b) and a bearing block to the wooden strip (3). Drill the hole (∅ 4.5) and saw everything out. Clean saw cuts with sandpaper.




Transfer the template (page 9) for the side parts to the two wooden strips (2). Drill the $\varnothing 2$ mm hole on the side parts (2a+2b). Saw out all parts and clean saw cuts.




Transfer the template on page 11 for the backrest (3d) and the handlebar mount (3e) to the second wooden strip (3).



Transfer the template for the fork (page 9) to the wooden strip (4). Then saw out the two fork parts (4a+4b), drill through and clean the saw cuts.



Glue the bottom panel (3b) to the side edge of the bottom panel (3a) as shown. Let the glue dry well.



Glue the side wall (2a) to the base plate as shown.

Instruction 101196
Easy Rider




Glue the front of the handlebar mount (3a) to the side panel as shown. (The hole points upwards!)




Glue the backrest (3b) opposite the handlebar mount as shown above.




Finally glue on the side part (2b). Let the glue dry well.




Finally glue on the side part (2b). Let the glue dry well.




Fasten the spring steel clip (21) with a screw (11) and a nut (12) to the hole provided in the base plate as shown.




Insert the reducer (17) into the gear hole (7). Then push the gear wheel onto the motor shaft of the motor (20).




Place the motor with the gear in the spring steel clamp (21) so that the gear is outside the base plate.




Measure the position of the hole on both parts (2e and 3c) and mark with a prick. Then drill both $\varnothing 5$ holes. Drive the brass sleeve (17) into the hole in part (2e). Drive the brass sleeve (18) into the hole in part (3c).



Cut the two wooden strips (1a+1b) to length as shown and clean the saw cuts.




Glue the wooden strip (1b) to the bearing block (2e) flush with the lower edge as shown. Also glue the wooden strip (1a) to the bearing block (3c) flush with the lower edge as shown.




Shorten one of the threaded rods (8) to 80mm and deburr it. Then insert through the opening of the bearing block (2e). Observe overlaps on both sides! Screw on and counter two nuts from each side. Then fasten a gear wheel (6) with two nuts (12) and two lock washers (14) on the left-hand side as shown above. Finally fasten a gear wheel (7) with two nuts (12) and two lock washers (14) on the opposite side. Glue the bearing block with the gears so that the large gear (6) meshes with the small gear (7) of the motor. Fix the bearing block and let the glue dry well.


Instruction 101196
Easy Rider




Shorten one of the threaded rods (8) to 135mm and deburr it. Then center it through the opening of the bearing block (3c). Screw on and counter two nuts from each side. Then screw on a toothed washer (14), a gear wheel (6), another toothed washer (14) and a nut (12). Finally, screw on a nut (12), a toothed washer (14), a wooden wheel (5), a toothed washer (14) and the cap nut (13). Screw on a nut (12), a toothed washer (14), a wooden wheel (5), a toothed washer (14) and the cap nut (13) on the opposite side. Glue the rear axle in such a way that the large gear meshes with the small gear of the previous axle! Fix the bearing block and let the glue dry well.



Shorten the remaining threaded rod (8) to 110mm and deburr it. For the fork, glue part (4b) onto part (4a) flush with the upper edge as shown. Make sure that the hole is vertical.




The 110mm long threaded rod F (M4) should be filed approx. 15mm on one end so that it fits into the hole in the cable connector.




Cut 2 pieces (approx. 100mm) from the wire (29) and strip the insulation on both sides. then solder a cable to each of the motor connections (20).


Instruction 101196
Easy Rider




Center the threaded rod (8) through the hole in the steering rod support. Attach the hard rubber disc (26) from above. Screw on a washer (15) and 2 nuts (12). Then attach the luster terminal (27) and screw tight. Screw on a washer (15) with two nuts (12) from the underside. Then screw on a nut (12) and a lock washer (14) again. Put on the fork and fasten it from below with a cap nut.





Bend the two welding wires about 20mm indented at one end by 125° as shown. Then attach the two wooden balls to the other end as shown and glue them in place.



Screw the two screw hooks (23) into the holes in the side panels as shown.



Connect the cables to the battery and fasten them to the screw hooks (23) using one of the rubber rings (25). Finished!



Battery connection with switch:




Install two screws (10) in the base plate, making sure they make secure contact with the tabs on the battery (see figure). Attach a cable to the screw (1) and connect the other end to the pole of the motor.

Make the switch from the brass strip (as shown above). Fasten this with 2 nuts on the screw (3) and screw them into the base plate so that the switch touches the screw (2) or closes the circuit.


Instruction 101196
Easy Rider

Template for side panels/ fenders
& storage block
M 1:1

Stencil fork
M 1:1



Template base plate/bearing block
M 1: 1



Template backrest and
Handlebar mount
M 1: 1

